



MOUNTING

The soft close damper mounts easily in the corner of the cabinet on the side where the hinge is located. To prevent damaging your cabinets, pilot drill 2.3 mm Ø [3/32"], 1/4" deep only, for a #6 x 3/4" pan head screw.

